

## Addendum

Due to some application requirements, the 0V on this product is isolated with respect to ground.

To meet the Electromagnetic Compatibility (EMC) performance specified in the Commander S100 User Guide, the user may need to connect 0V and Ground



0500-0016-01